

ROCKSTEADY® CLIP INSTALLATION GUIDELINES

INSTRUCTIONS AND WARRANTY

CAREFULLY READ ALL THESE INSTALLATION GUIDELINES AND INSTRUCTIONS PRIOR TO USE. THE ROCKSTEADY® CLIP'S SAFE AND INTENDED USE AS A DRYWALL STABILIZING SYSTEM IS TO KEEP DRYWALL SECURED IN A LEANING POSITION SO THAT IT CANNOT BE PULLED FORWARD.

WARNING. DO NOT USE THE ROCKSTEADY® CLIP EXCEPT IN ACCORDANCE WITH THESE INSTALLATION GUIDELINES:

- The RockSteady® Clip is designed to stabilize drywall when stacked against wood framing with a minimum 2"x 4" stud wall or metal studs with a gauge of 16, 18 or 20, only when sheathing has first been attached to the opposing wall. Never install the RockSteady® Clip into 25 gauge metal stud walls.
- Vertically stacked drywall must always be placed four to six inches from the wall at the bottom of the stack. Failure to do so may result in serious harm or injury.
- Place one clip every 6' (feet) and not less than 2' (feet) from butt end of drywall sheet. Sheets over 12' (feet) require 2 clips.
- Ensure that the cable is pulled tight while driving down the set screw. Ensure that the set screw is completely compressed/tightened, with the cable pinched between the set screw head and the top of the RockSteady® Clip
- Once secured with the RockSteady® Clip, in accordance with the installation instructions and guidelines, a minimum of two hundred fifty pounds of pulling force is required to pull the drywall stack forward. Independent Third Party Testing Companies have tested our product and certified the results. [Test criteria and results](#) are available in their entirety on the RockSteady website.
- Match drywall thickness to clip size. White RockSteady® Clips are for use with 1/2" drywall only. Gray RockSteady® Clips are for use with 5/8" drywall only.
- The RockSteady® Clip is safe and warranted to one installation of eye end of screw into the framing member and is intended for use in the depletion of one stack of drywall. The maximum limits are 26 sheets for 5/8" thick drywall and 34 sheets of 1/2" drywall. All other materials, reuse or number of sheets exceeding the prescribed limits are strictly prohibited and will void all warranties.

INSTALLATION INSTRUCTIONS

Step #1

With a screw gun, drive the screw (provided) at eye end of cable through the eye into the side of the framing stud. Keeping the screw and cable level with the top edge of drywall, no less than 1" from outside edge of framing. (see photo Step #1)



Step #2

Place the RockSteady® Clip over the outer most sheet on stack. The warning label must be clearly visible. No space should remain between clip and drywall edge. Pull cable tight while driving down set screw. The set screw must be completely compressed / tightened, with the cable pinched between the set screw head and the top of the RockSteady® Clip. After removing each sheet for installation, reattach the clip following the same procedure until the stack is depleted. (see photo Step #2) After use, dispose of the clip properly by placing in refuse container, recycling in accordance with local requirements or leave attached inside wall cavity.



WARNING. THE ROCKSTEADY® CLIP MAY ONLY BE USED ON A SINGLE STACK OF DRYWALL CONTAINING A MAXIMUM OF 26 SHEETS OF 5/8" (INCH) THICK DRYWALL OR 34 SHEETS OF 1/2" (INCH) THICK DRYWALL. THE CLIP MUST BE DISCARDED AFTER THIS SINGLE USE AND MAY NOT BE REUSED.

ROCKSTEADY® CLIP LIMITED WARRANTY

ROCKSTEADY EXPRESSLY WARRANTS TO THE ORIGINAL PURCHASER THAT THE ROCKSTEADY® CLIP WILL PERFORM ITS INTENDED FUNCTION FOR ONE SINGLE USE, IF INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS. PURCHASER'S EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY AND ROCKSTEADY'S OBLIGATION UNDER THIS WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF THE NON-PERFORMING CLIP. THIS WARRANTY APPLIES ONLY TO THE USE OF THE PRODUCT AS INTENDED BY SELLER AND IS VOID IF THERE IS ANY MISAPPLICATION, MISUSE OR ABUSE OF THIS PRODUCT, ABNORMAL USE, ACTS OF GOD, FIRE OR FLOOD, OR IMPROPER ASSEMBLY OR REPAIR, OR DAMAGE IN SHIPPING. THIS WARRANTY SHALL RUN ONLY TO THE FIRST PURCHASER OF THE ROCKSTEADY® CLIP FROM ROCKSTEADY OR FROM ROCKSTEADY'S DISTRIBUTOR AND IS NON-ASSIGNABLE AND NON-TRANSFERABLE AND SHALL BE OF NO FORCE AND EFFECT IF ASSERTED BY ANY PERSON OTHER THAN THE FIRST PURCHASER.

ROCKSTEADY MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, AND THOSE ARISING FROM A COURSE OF DEALING, COURSE OF PERFORMANCE, OR USAGE OF TRADE. UNDER NO CIRCUMSTANCES WILL ROCKSTEADY BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES, INCLUDING ANY DAMAGES RELATED TO LOST PROFITS, LOSS OF BUSINESS OR LOSS OF GOODWILL.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

ROCKSTEADY® CLIP is not intended or warranted under the following conditions:
Purposeful or malicious attempts to remove the clip or to pull drywall away from wall by one or more individuals in the act of causing harm or destruction of property.
The warranty specifically excludes reuse of the ROCKSTEADY® CLIP.

THE ROCKSTEADY® CLIP INSTALLATION GUIDELINES AND INSTRUCTIONS ON PAGE ONE OF THIS DOCUMENT MUST BE FOLLOWED CAREFULLY AND COMPLETELY.

Choice of Law.

All disputes regarding Warranty Claims shall be adjudicated in the Federal or State courts of the Commonwealth of Pennsylvania, which shall have exclusive jurisdiction over any dispute.

Additional information and installation video available at:

www.rocksteadyclip.com

For Customer Service Contact us:

by e-mail: mail@rocksteadyclip.com

by phone: 1-877-RCKSTDY or 1-877-725-7839

by mail: RockSteady, LLC 112 N. Cedar St. Lititz, PA 17543

©2009 RockSteady, LLC, ALL RIGHTS RESERVED

Patent Pending #11/953.546 Made in the U.S.A.

The information contained herein replaces and updates all previous installation guidelines, instructions and warranty documentation for the RockSteady® Clip rev. 002 9-2-09, RockSteady, LLC